



## Instructions for Operating Scoreboards at Greenwood, West Middle School, and Parkers Lake

1. Install the DAK Score app from Google Play or the App Store.



2. When you open the app, DAK Score will look for nearby scoreboard control boxes. The app connects to the control boxes via Bluetooth, so be sure you have Bluetooth enabled on your device.
3. Select the name of the scoreboard you want to control from the list – e.g., Greenwood 1, Parkers Lake 6, etc. – and you will be brought to an interface to control the scoreboard.
  - Please do not change any of the settings of the scoreboard via the app (broadcast group, channel), since this will unlink the scoreboard from the control box.
4. When you are finished scoring, select “Disconnect” from the menu at the top left, and be sure to select **“Turn off & Disconnect”** so the scoreboard turns off.